

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

NEW MEXICO OIL CONSERVATION COMMISSION
JUL 9 1971

O. O. O.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 647

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name M. Yates
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 5
4. Location of Well UNIT LETTER G 1980 FEET FROM THE North LINE AND 1980 FEET FROM East 33 TOWNSHIP 17-S RANGE 28-E NMPM.	10. Field and Pool, or Wildcat Artesia-Grayburg
15. Elevation (Show whether DF, RT, GR, etc.) 3667' GR	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well produces about 1 BOPD and no water. It is no longer economical to produce and no remedial possibilities exist. We propose to P & A as outlined below:

1. Place 30 sx cement from 1890'-1970' (7" shoe @ 1940').
2. Cut off & recover 7" casing from free point.
3. Spot 30 sx cement in & out of 7" stub.
4. Spot 30 sx cement across 8-5/8" shoe @ 515'.
5. Place 10 sx of cement in top of well.

Leave 9#/gal gel mud between all cement plugs. Erect dry hole marker. Clear & level location. 8-5/8" casing will remain intact.

18. I hereby ce

the information above is true and complete to the best of my knowledge and belief.

SIGNED W. A. Gressett

TITLE Dist. Drlg. Supervisor

DATE 7/7/71

APPROVED BY W. A. Gressett

TITLE OIL AND GAS INSPECTOR

DATE

CONDITIONS: None, IF ANY:

JUL 21 1971