

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

## OIL CONSERVATION DIVISION

2040 Pacheco St.  
Santa Fe, NM 87505

WELL API NO. 30-015-01740
Indicate Type of Lease STATE _____ FEE _____
State Oil & Gas Lease No.
Lease Name or Unit Agreement Name Empire Abo Unit "F"
Well No. F # 40
Pool name or Wildcat ABO

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
Name of Operator BP America	
Address of Operator P.O. Box 1089 Eunice New Mexico 88231	
Well Location Unit Letter <u>H</u> : <u>1650</u> Feet From The <u>North</u> Line and <u>990</u> Feet From The <u>East</u> Line 35 Section 17S Township 28E Range NMPM Eddy N.M. County	
Elevation (Show whether DF, RKB, RT, GR, etc.) 3671 GR	

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

### SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ANBANDONMENT ☒  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU 9-23-02  
9-25-02 Tag CIBP @ 6122'.  
10-2-02 Pump 25 sx on top of CIBP. WOC Tag @ 5980'.  
10-3-02 Perf @ 3600'. Not able to pump in.  
10-4-02 Spot 25 sx 3651'. Perforate @ 2163' TIH Packer Set @ 1700' Not able to pump in. Spot 25 sx @ 2163'.  
10-7-02 WOC & Tag @ 1896'. Perforate @ 807'. Set Packer @ 400' Not able to pump in. Spot 25 sx @ 862'.  
10-8-02 WOC Tag Plug @ 625'.  
10-9-02 Perf @ 530'. Set packer @ 200'. Squeeze 60 sx. WOC  
10-10-02 tag @ 225' Perf @ 225' Set Packer @ 30' Squeeze 35 sx.  
10-14-02 Well leaking. MIRU Reverse unit Drill out to 368'. 10-15-02 Drill out to 552'. 10-16-02 Pump 500 gallons acid.  
10-17-02 Set CICR @ 180'. Pump 400 sx Class H & 200 sx Class C.  
10-21-02 Rig up reverse unit 10-22-02 Drill out retainer to 265'. 10-23-02 Drill out to 530'. 10-24-02 Set packer 100' Pump 400 sx Thickset & 200 sx Class C Lockup 2500 PSI.  
10-28-02 Plug Leaking. 10-29-02 Rig Up reverse Unit Drill to 210'. 10-30-02 Spot 10 sx Keep 2500 PSI on plug all day. 10-31-02 Drill to 320'.  
11-01-02 Drill out to 556'. 11-4-02 Spot 45 sx @ 550'. Set Retainer @ 186'. Sting in Pressure up to 1500 PSI Sting out. Top CICR 10 sx Cement perf @ 60' Pump 350 sx Class H W/ Packer @ 30'. 11-6-02 Spot surface Plug Cut off well head & install dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

DATE

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: