

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYO.C.D. COPY
SURFACE TRIPLICATE
(Other instruction
reverse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC-067610-a

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

RECEIVED

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Bosworth

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

High Lonesome

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 14, T-16S, R-29E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection
2. NAME OF OPERATOR General American Oil Company of Texas ✓
3. ADDRESS OF OPERATOR P. O. Box 128 Loco Hills, New Mexico 88255
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL and 2310' FEL
14. PERMIT NO.
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3704' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)			

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
(Other)			

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 7" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug 2059'-1959'.
(This will cover open hole section 2029'-2059').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 920'-820'. (Base of Salt 870').
7. Set 100' cement plug from 505'-405'. (Top of Salt 455').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.

18. I hereby certify that the foregoing is true and correct

SIGNED Pendell M. HawkinsTITLE Field SuperintendentDATE February 5, 1981

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTERTITLE ACTING DISTRICT ENGINEERDATE FEB 10 1981

CONDITIONS OF APPROVAL, IF ANY: