

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate
GEOLOGICAL SURVEY
FORM NO. 100

Budget Bureau No. 42 R1424

LC-067610-a

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER Water Injection

2. NAME OF OPERATOR
General American Oil Company of Texas

3. ADDRESS OF OPERATOR
P. O. Box 128 Loco Hills, New Mexico 88255

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
990' FSL and 990' FEL

14. PERMIT NO. _____

15. ELEVATION (Show whether DT, RT, GR, etc.)
3719' DF

7. UNIT AGREEMENT NAME SEC 14

8. FARM OR LEASE NAME
Bosworth SEP 18 1981

9. WELL NO.
4

10. FIELD AND POOL, OR WHOLET
High Lonesome

11. SEC., T., R., M., OR BLM. AND
SURVEY OR AREA
Sec. 14, T-16S, R-29E

12. COUNTY OR PARISH
Eddy

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEXT WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
KHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
KHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input checked="" type="checkbox"/>
(Other)	<input type="checkbox"/>		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE TECHNIQUE OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The following work was completed March 20 — 26, 1981

1. Tubing and packer pulled.
2. Set 145 sack plug, 2079'-1400', (Open hole section 2079'-2050').
3. No casing determined free.
4. Perforated 4 holes at 888' and squeezed 55 sacks cement into Base of Salt, (Plug inside casing 938'-800').
5. Perforated 4 holes at 460' and squeezed 55 sacks cement into Top of Salt and the water zone.
6. Set 25 sack plug inside casing to plug to 300'.
7. Set 10 sack plug at surface.
8. Permanent dry hole marker installed.

Additional report will be submitted when the location is cleaned-up at the end of the 10 well abandonment program.

18. I hereby certify that the foregoing is true and correct

SIGNED M. S. Samsing TITLE Engineer DATE March 27, 1981

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side