

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instruction
verse side)Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

LC-061638

6 IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR General American Oil Company of Texas /		8. FARM OR LEASE NAME Brewer	
3. ADDRESS OF OPERATOR P. O. Box 128 Loco Hills, New Mexico		9. WELL NO. # 20	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FNL and 1980' FWL		10. FIELD AND POOL, OR WILDCAT High Lonesome	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 14, T-16S, R-29E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3717' DF		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 5-1/2" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug, 2052'-1952'.
(This will cover open hole section 2023'-2052').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 935'-835'. (Base of Salt 885').
7. Set 100' cement plug from 480'-380'. (Top of Salt 430').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.

18. I hereby certify that the foregoing is true and correct

SIGNED

Rendell H. Hawkins

TITLE Field Superintendent

DATE February 5, 1981

(This space for Federal or State office use)

(Orig. Sgd.) PETER W. CHESTER

APPROVED BY

TITLE ACTING DISTRICT ENGINEER

DATE FEB 10 1981

CONDITIONS OF APPROVAL, IF ANY: