

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions
reverse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC-061638

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection
2. NAME OF OPERATOR General American Oil Company of Texas ✓
3. ADDRESS OF OPERATOR P. O. Box 128 Loco Hills, New Mexico 88255
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL and 660' FWL
14. PERMIT NO.
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3699' DF

7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME Brewer
9. WELL NO. # 27
10. FIELD AND POOL, OR WILDCAT High Lonesome
11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA Sec. 14, T-16S, R-29E
12. COUNTY OR PARISH Eddy
13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 7" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug, 2036'-1936'.
(This will cover open hole section 2002'-2036').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 885'-785'. (Base of Salt 835').
7. Set 100' cement plug from 470'-370'. (Top of Salt 420').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.

18. I hereby certify that the foregoing is true and correct

SIGNER Rendell H. Hawkins TITLE Field Superintendent DATE February 5, 1981

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE ACTING DISTRICT ENGINEER DATE FEB 10 1981
CONDITIONS OF APPROVAL, IF ANY: