

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)Form approved.  
Budget Bureau No. 42-R1424.  
Copy to S.F.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. <b>LC 068628</b>	
2. NAME OF OPERATOR <b>Sun Oil Company - DX Division</b>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR <b>P. O. Box 1416 - Roswell, New Mexico 88201</b>		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <b>2310 PSL &amp; 1650 FWL</b>		8. FARM OR LEASE NAME <b>Donohue Federal</b>	
14. PERMIT NO.		9. WELL NO. <b>2</b>	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) <b>3687 GR</b>		10. FIELD AND POOL, OR WILDCAT <b>High Lonesome</b>	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <b>Sec. 15, T-16-S, R-29-E</b>	
		12. COUNTY OR PARISH <b>Eddy</b>	
		13. STATE <b>New Mexico</b>	

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

**NOTE:** Well is producing 100% water and there are no apparent economical potential producing zones. Plan is to plug and abandon lease according to the following program.

1. TD 1944. 5-1/2" casing at 1897. Calculate cement top at 1600'.
2. Load hole with mud-laden fluid.
3. Lay 25 sack plug from TD to 1850.
4. Cut 5-1/2" casing at approximately 1500' and pull out of hole.
5. Lay 25 sack plug in and out of 5-1/2" casing stub.
6. Lay 25 sack plug from 700' to 800' to cover base of salt.
7. Lay 25 sack plug in and out of bottom of 8-5/8" casing. Top of salt is at 400'.
8. Place 10 sack plug at surface and install dry hole marker.
9. Clean up lease for inspection.

RECEIVED

APR 3 1969

O. C. C.

ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct

SIGNED

F. D. Lebo

TITLE

District Engineer

DATE

March 25, 1969

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side