rorm	3160	-5	
Nove	mber	1983)	
- Com	arly	0-331	١

## UN' TED STATES DEPARTME. OF THE INTERIOR (Other Instruction verse side)

Expires August 31, 1985 5. LEASE DERIGNATION AND SERIAL NO.

BUREAU OF LAND MANAGEMENT Mn

LC-037777(b) 6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY N	OTICES	AND	REPORTS	ON	WELLS
----------	--------	-----	---------	----	-------

	(Do not use this form for proposa Use "APPLICA"	is to drill or to deepen or plug back to a different reservoir. TION FOR PERMIT—" for such proposals.)				
1.		. / . n 4 /	7. UNIT AGREEMENT NA	ME		
	OIL GAB OTHER		Forest Pool	Unit		
2.	NAME OF OPERATOR		8. FARM OR LEASE NAM	(R		
	Marbob Energy Corporat	tion $\sqrt{}$	Forest Pool	Unit		
3.	ADDRESS OF OPERATOR		9. WELL NO.			
	P.O. Drawer 217, Artes	sia, N.M. 88210	8			
4.	LOCATION OF WELL (Report location cle See also space 17 below.)	arly and in accordance with any State requirements.	10. FIELD AND POOL, OF	WILDCAT		
	At surface		Square Lake G SA			
	1980 FNL 660	FEL	11. SRC., T., R., M., OR BLK. AND SURVET OR ARMA			
			Sec. 34-T16S	-R29E		
14.	PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH	18. STATE		
		3659' GR	Eddy	N.M.		

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:			
PRACTURE TREAT SHOOT OR ACIDIES REPAIR WELL (Other)	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON® CHANGE PLANS	X	WATER SHUT-OFF  FRACTURE TREATMENT  SHOOTING OR ACIDIZING  (Other)  (Note: Report results of Completion or Recompletic	ABANDONMENT*  multiple completion on Wellon Bepart and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and sones pertinent to this work.) \*\*

16.

We propose to plug and abandon as follows: 8 5/8" casing is set @ 402' w/50 sax cement; 5½" casing is set @ 2650' w/25 sax cement. We will circulate hole w/mud laden fluid; spot 100 sack cement plug @ 2675'; circulate to surface; if we cannot circulate - squeeze 50 sax out of casing and 25 sax in casing; tag; perforate @ 350' and attempt to circulate; if we cannot circulate - squeeze 100 sax cement thru perfs; tag; set 15 sack plug at surface; set dry hole marker; level and clean location.

RECEIVED BY

FEB 07 1986

O. C. D. ARTESIA, OFFICE

18. I hereby cartify that the foregoing is true and correct				
SIGNED Wante Ca		Production Clerk	DATE _	1/16/86
(This space for Federal or State office use)				- 1 - la
APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE		DATE	2.6.86

Subject to Like Approval

\*See Instructions on Reverse Side