

N.M.O.C.D. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ *Water Injection*
2. NAME OF OPERATOR
General American Oil Company of Texas
3. ADDRESS OF OPERATOR
P. O. Box 128, Loco Hills, New Mexico 88255
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
2310' FNL and 330' FEL

RECEIVED
NOV 16 1979
U.S. GEOLOGICAL SURVEY
ALBUQUERQUE, NEW MEXICO

NM-012764
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Nunlee
9. WELL NO.
#5
10. FIELD AND POOL, OR WILDCAT
Square Lake
11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec. 35, T-16-S, R-29-E
12. COUNTY OR PARISH
Eddy
13. STATE
New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, or FEL, or FNL)
3678' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐
REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

The following work was done:

1. Ran 2" tubing to 2500'. Set 150' cement plug from bridge plug @ 2500' back to 2350'.
2. Ran Free Point. Free Point indicated 5 1/2" casing stuck @ 562' and free @ 550'. Consulted USGS and it was recommended to cut casing off @ 550' and set 100' cement plug, (50' inside and 50' outside) from 500' back to 400'.
3. Casing was cut @ 550'.
4. After one joint of casing was pulled, water flow was encountered.
5. USGS was consulted and it was recommended to squeeze to shut off water flow.
6. Shut well in and pressure stablized @ 170#. Rigged up and block squeezed formation with 400 sacks of Class C cement with 3% CaCl. Shut well in.
7. Water flow was shut off. Tagged cement inside of 5 1/2" casing 5' below surface.
8. Ran 200' of 3/4" tubing between 8 5/8" and 5 1/2" casing. Circulated cement to surface.
9. Filled remaining 5' of 5 1/2" with cement and installed dry hole marker.
10. Awaiting instructions from BLM concerning the ripping of pad and access road.

18. I hereby certify that the foregoing is true and correct

SIGNED Randell Hawkins TITLE Asst. Field Superintendent DATE November 15, 1979

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE ACTING DISTRICT ENGINEER

DATE