

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

RECEIVED BY  
SEP 07 1983

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen a well. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☐ other Water Injection Well

2. NAME OF OPERATOR

Stamford Natural Resources Group 1980-1

3. ADDRESS OF OPERATOR

P. O. Box 2249

c/o S & J Operating Co. Wichita Falls, TX 76307

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

Sec. 1, T16S, R30E

AT SURFACE: Unit F, 2006.6 FNL, 1980 FWL

AT TOP PROD. INTERVAL: 3031'

AT TOTAL DEPTH: 3068'

15. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE.  
REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

PULL OR ALTER CASING

MULTIPLE COMPLETE

CHANGE ZONES

ABANDON\*

other)

SUBSEQUENT REPORT OF:

5. LEASE

Fed. NM-06407-A

6. INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

East Henshaw Unit

8. FARM OR LEASE NAME

East Henshaw Unit, Tract 6

9. WELL NO.

6-1

10. FIELD OR WILDCAT NAME

West Henshaw-Grayburg

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 1, T16S, R30E, NMPM

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
KB-3964

(NOTE: Report results of multiple completions or zone change on Form 9-330.)

RECEIVED  
JUL 12 10 59 AM '83  
BUR. OF LAND MGMT  
ROSVELL DISTRICT

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

S & J Operating has planned the following plug and abandon procedure for well #1 of the East Henshaw Unit, T16N R30E, Tract #6, Eddy County, New Mexico, on or around August 22, 1983:

- 1) Pull 2 3/8" tubing
- 2) Set cast iron bridge plug in 4 1/2 casing @ 2978' (perforations 3031-3046); dump bail 35 ft. of cement on top of bridge plug.
- 3) Run Acoustic Log to determine casing cement top of 4 1/2" casing.
- 4) Shoot casing off @ cement top and retrieve.
- 5) Set 100' cement plug @ casing stub. (50' in, 50' out).
- 6) Set 100' cement plug above Yates Formation (i.e. 1550'-1450').
- 7) Set 100' cement plug @ base of surface casing (i.e. 530'-430').
- 8) Set 50' cement surface plug.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Bud Newton*

TITLE Petr. Eng.

DATE 7/9/83

APPROVED

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.)

PETER W. CHITTER

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

SEP 2 1983

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands, pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be found by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, the items on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.