

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Mack Energy Corporation

3. Address and Telephone No.

P.O. Box 960, Artesia, NM 88211-0960 (505)748-1288

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FSL 1980 FWL
Sec. 8-T16S-R30E

5. Lease Designation and Serial No.

NM-04068

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Sivley Federal #3

9. API Well No.

30-015-03873

10. Field and Pool, or Exploratory Area

West Henshaw Grayburg

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Circ hole w/mud laden fluid.
2. Set cmt plug from PBTD to 50' above all perf
3. Tag cmt plug @ 2701'.
4. Perf csg 50' below base salt (1123').
5. Squeeze perfs w/25sx cmt plug.
6. Tag plug @ 1023'.
7. Perf csg 50' below top salt (535').
8. Squeeze perfs w/25sx cmt plug.
9. Tag cmt plug @435'.
10. Perf csg @ 60'. AD will
11. Squeeze perf w/cmt. Attempt to circ all csg to surface.
12. Install dry hole marker and clean location.
13. We will need a workover pit on this location.

RECEIVED

APR 27 1995

OIL CON. DIV.
DIST. 2

CART AREA

APR 7 3 09 PM '95

RECEIVED

14. I hereby certify that the foregoing is true and correct

Signed Crisse D. Carter

Title Production Clerk

Date 4-7-95

(This space for Federal or State office use)

Approved by Orig. Signed by Adam Salameh

Title Petroleum Engineer

Date 4/25/95

Conditions of approval, if any:

- SEE ATTACHED -

BUREAU OF LAND MANAGEMENT
CARLSBAD RESOURCE AREA

Permanent Abandonment of Wells on Federal Lands

Conditions of Approval

1. **Approval:** Plugging operations shall commence within 90 days from the approval date of plugging procedure.

2. **Notification:** Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Eddy County call (505) 887-6544 ; for wells in Lea County call (505) 393-3612.

3. **Blowout Preventers:** A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet ; and a 5M system for a well not deeper than 22,727 feet.

4. **Mud Requirement:** Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.

5. **Cement Requirement:** Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either class "C" , for up to 7,500 feet of depth, mixed at 14.0 lbs./gal. with 6.3 gallons of fresh water per sack or class "H" , for deeper than 7,500 feet plugs, mixed at 16.4 lbs./gal. with 4.3 gallons of fresh water per sack.

6. **Dry Hole Marker:** All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: Well name and number, the name of the operator, the lease serial number, the surveyed location (the quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer; such as metes and bounds).

7. **Subsequent Plugging Reporting:** Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.

Following the submittal and approval of the Subsequent Report of Abandonment, surface restoration conditions of approval will be developed and furnished to you.

MACK ENERGY CORPORATION

SIVLEY FEDERAL #3
SEC 8 T16S R30E 1980FSL 1980FWL

WELL HISTORY

PBTD: 2785'
TD: 3623'
SP Csg: 10 3/4" 32.75# @ 518' C/w 50
LS Csg: 7" 23# @ 2751' C/w 150sx
T SALT: 485'
B SALT: 1073'
PERFS: Open hole 2751-85

COMPLETION REPORT


12-7-58 Frac open hole w/54,000 gals oil and 900sx sand.

WELL REPORT

5-15-85 Rigged up. Ran in hole w/7" csg scrapper and clean out to 2740'. Circ hole w/2% KCL water. Pulled out hole. Ran in hole w/7" Arrow Pkr and plug. Set plug at 2700'. Tested csg to 500#. Held OK.


3-31-95 PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

- 1 Circ hole w/mud laden fluid
- 2 Set cmt plug from PBTD to 50' above all perfs.
- 3 Tag cmt plug @ 2701'
- 4 Perf csg 50' below base salt (1123')
- 5 Squeeze perfs w/25sx Cmt plug
- 6 Tag plug @ 1023'
- 7 Perf csg 50' below top salt (535)
- 8 Squeeze perfs w/25sx Cmt plug
- 9 Tag cmt plug @ 435'
- 10 Perf csg @ 60'
- 11 Squeeze perfs w/cmt. Attempt to circ all csg to surface.
- 12 Install dry hole marker and clean location
- 13 We will need a workover pit on this location.



MACK ENERGY CORPORATION
 WELL DIAGRAM
 SIVLEY FEDERAL # 3
 SEC 8 T16S R30E
 1980FSL 1980FWL

WELL DIAGRAM BEFORE
 PREPARE BY
 ROBERT CHASE



MACK ENERGY CORPORATION
 WELL DIAGRAM
 SIVLEY FEDERAL # 3
 SEC 8 T16S R30E
 1980FSL 1980FWL

WELL DIAGRAM AFTER
 PREPARE BY
 ROBERT CHASE