

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN
(Other instru
verse side)

DATE
or re-

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
Federal Bogle NM-01146

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME ---
2. NAME OF OPERATOR Humble Oil & Refining Company ✓		8. FARM OR LEASE NAME Federal Bogle
3. ADDRESS OF OPERATOR P. O. Box 2100, Hobbs, New Mexico 88240		9. WELL NO. 2
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' North of South line and 1980' East of West Line, Sec. 30, T-16-S, R-30-E, Eddy County, New Mexico		10. FIELD AND POOL, OR WILDCAT Square Lake
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 30, T-16-S, R-30-E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3720 D. F.		12. COUNTY OR PARISH Eddy
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
Plug ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Pull rods and tubing.
2. Set cement plug from 2773' to 2650' with 15 sacks.
3. Cut 5" casing at 2190' and pull same.
4. Set cement plug from 2250' to 2150' with 21 sacks.
5. Set cement plug from 1650' to 1550' with 30 sacks.
- * 6. Place cement plug from 540' to 490' with 15 sacks.
7. Set cement plug from 20' to 0 with 6 sacks.
8. Mud laden fluid between all plugs.
9. Install marker as required by New Mexico Oil Conservation Commission.

* Approval subject to:

Increasing the length of this plug to - 40 -

RECEIVED

RECEIVED

AUG 11 1965

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Dist. Adm. Supvr.

DATE August 10, 1965

(This space for Federal or State office use)

APPROVED

APPROVED BY
AUG 11 1965
RUDOLPH C. BAIER, JR.
ACTING DISTRICT ENGINEER

TITLE

DATE

*See Instructions on Reverse Side