

COPIES RECEIVED	3
DISTRIBUTION	
FE	1
U.S.G.S.	1
LAND OFFICE	
OPERATOR	1

**RECEIVED**  
**NEW MEXICO OIL CONSERVATION COMMISSION**  
**JUN 1 1982**  
**O. C. D.**  
**ARTESIA, OFFICE**

Form C-103  
 Supersedes Old  
 C-102 and C-103  
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-2884	
7. Unit Agreement Name Square Lake Flood	
8. Farm or Lease Name (West) Continental State	
9. Well No. 1	
10. Field and Pool, or Wildcat Square Lake (G-SA)	
12. County Eddy	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- TA - WIW
2. Name of Operator Newmont Oil Company ✓
3. Address of Operator P. O. Box 1305, Artesia, New Mexico 88210
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 16S RANGE 30E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3794' GLM

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well as follows:

1. Spot 50 sack cement plug across producing interval and tie back to production string casing seat. If well is flowing set bride plug near casing seat and cap with 35 sack cement plug.
2. Perforate at base of salt and squeeze with 50 sacks cement.\* + Tag
3. Perforate at top of salt and squeeze with 50 sacks cement.\* + Tag
4. Set 15 sack cement plug at surface down surface and production casing.
5. Erect permanent well marker.

NOTE: a. Your office will be notified 24 hrs. prior to operations.  
 b. All plugs will be tagged.  
 c. Hole will be loaded between all plugs with 10# Mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Area Manager DATE 6/1/82

APPROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE JUN 4 1982

CONDITIONS OF APPROVAL, IF ANY: \* As Noted Above