

UNITED STATES OF AMERICA
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYINSTRUCTIONS TO THE FIELD
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

JUN 14 1982

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	TA - WIW	O. C. D.	5. LEASE DESIGNATION AND SERIAL NO. LC-056302 (b)
2. NAME OF OPERATOR Newmont Oil Company V	ARTESIA, OFFICE		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 1305, Artesia, N.M. 88210			7. UNIT AGREEMENT NAME Square Lake Flood (East)
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FSL & 660' FWL of Section 28			8. FARM OR LEASE NAME Johnson
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3976' GLM		9. WELL NO. 2
			10. FIELD AND POOL, OR WILDCAT Square Lake (G. SA)
			11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 28-16S-31E
		12. COUNTY OR PARISH Eddy	13. STATE N.M.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to plug and abandon the above well as follows:

1. Pull tubing and packer.
2. Spot 50 sack cement plug across producing interval and tie back to production string casing seat. If well is flowing set bridge plug near casing seat and cap with 35 sack cement plug.
3. Perforate at base of salt and squeeze with 50 sacks cement *
4. Perforate at top of salt and squeeze with 50 sacks cement. *
5. Set 15 sack cement plug at surface down surface and production casing.
6. Erect permanent well marker.

Note: (a) Your office will be notified 24 hrs, prior to operations.
(b) All plugs will be tagged
(c) Hole will be loaded between all plugs with 10# mud
(d) We do not plan to pull any casing

* Leave 100' cement plug inside casing across from perf.

18. I hereby certify that the foregoing is true and correct.

SIGNED *Peter W. Chester*

TITLE Area Manager

DATE 6/3/82

(This space for Federal or State Approval)
(Orig. Sgd.) PETER W. CHESTER

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JUN 11 1982

FOR

JAMES A. GILLHAM *See Instructions on Reverse Side
DISTRICT SUPERVISORRECEIVED
JUN 4 1982