

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVING  
OFFICE FOR NUMBER  
OF COPIES REQUIRED  
(Other instructions on re-  
verse side)

BLM Roswell District  
Modified Form No.  
NMO60-3160-4

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER P&A		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR YATES PETROLEUM CORPORATION		8. FARM OR LEASE NAME Bruning	
3. ADDRESS OF OPERATOR 105 South 4th St., Artesia, NM 88210		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL, 660' FWL, Sec. 29-T16S-R31E		10. FIELD AND POOL, OR WILDCAT Square Lake G-SA	
14. PERMIT NO. 30-015-04911		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Unit E, Sec. 29-16S-31E	
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 3903' GR		12. COUNTY OR PARISH Eddy	
		13. STATE NM	

10. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
(Other) <input type="checkbox"/>	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

Propose to plug well as follows:  
Open tubing and flow well down to pit. Pull tubing and packer.  
GIH w/tubing to TD and spot 35 sx cement plug.  
Pull tubing up and WOC. Tag plug at 3350' or higher (50' above 4½" liner top).  
Perforate 4 squeeze holes at 1800' (below base of salt).  
Set cement retainer on wireline and set at 1700'.  
GIH w/tubing and pump 100 sx cement under retainer. Sting out and leave 10 sx on top retainer.  
Cut and pull 5½" casing at 500'.  
Set cement retainer on wireline at 450'.  
GIH w/tubing and pump 150 sx cement under retainer. Sting out and leave 50' cement on top of retainer.  
Perforate 4 squeeze holes in 8½" casing at 300'.  
Tie on to casing and attempt to circulate. If possible circulate 8½" casing w/cement and leave 100' cement above perms. If not possible to circulate, spot cement on perms and displace out 50-100 sx. Leave 100' cement inside casing above perms. Tag this plug.  
Set surface plug and install abandonment marker.

18. I hereby certify that the foregoing is true and correct

SIGNED Jamesita Doodler

TITLE Production Supervisor

DATE 4-20-90

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

\*See Instructions on Reverse Side