

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

RECEIVED

DEC 11 1991

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other P&A

2. Name of Operator

YATES PETROLEUM CORPORATION ✓ (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit A, 660' FNL, 660' FEL, Sec. 30-T16S-R31E

5. Lease Designation and Serial No.

LC 029431

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Vickers #2

9. API Well No.

30-015-04934

10. Field and Pool, or Exploratory Area

Square Lake-G-SA

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

AMENDED P&A PROCEDURE. Propose to P&A well as follows:

1. Pull tubing and packer. RIH open-ended to  $\pm 3200'$  and spot 35 sx cement plug. POH w/tubing.
2. RIH w/perf gun and shoot 4 holes @ 2450' (Queen Sand) and @ 600' (T. of Salt).
3. RIH w/tubing and retainer. Set @ 2400' and squeeze w/50 sx Class "C" w/2% CaCl<sub>2</sub>.
4. Set 35 sx plug across holes @ 1200'.
5. Set retainer at  $\pm 550'$  and squeeze T. of Salt w/50 sx Class "C" w/2% CaCl<sub>2</sub>.
6. POH w/tubing. Tie onto casing w/cementing head and pump thru holes at 250' and establish circulation. Cement w/50 to 100 sx Class "C". After circulating cement, shut cement head in for 12 hours.
7. Remove cement head and run 1 joint tubing. Cement w/10 sx cement.

NOTIFY BLM 24 HOURS BEFORE PLUGGING BEGINS.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title Production Supervisor

Date 12-10-91

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title \_\_\_\_\_

Date 12/16/91