

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
 NOV 14 1972
O. C. C.
 ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator NEWMONT OIL COMPANY		5. State Oil & Gas Lease No. B-2721
3. Address of Operator P. O. BOX 1305, ARTESIA, NEW MEXICO 88210		
4. Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 32 TOWNSHIP 16S RANGE 31E NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.) 3944'		7. Unit Agreement Name 8. Farm or Lease Name State "R" 9. Well No. 3 10. Field and Pool, or Wildcat Square Lake G. SA.
		12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO:

<input type="checkbox"/> PERFORM REMEDIAL WORK	<input type="checkbox"/> PLUG AND ABANDON
<input type="checkbox"/> TEMPORARILY ABANDON	<input type="checkbox"/> CHANGE PLANS
<input type="checkbox"/> PULL OR ALTER CASING	<input type="checkbox"/> OTHER _____

SUBSEQUENT REPORT OF:

<input type="checkbox"/> REMEDIAL WORK	<input type="checkbox"/> ALTERING CASING
<input type="checkbox"/> COMMENCE DRILLING OPNS.	<input checked="" type="checkbox"/> PLUG AND ABANDONMENT
<input type="checkbox"/> CASING TEST AND CEMENT JOBS	<input type="checkbox"/> OTHER _____

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10/20/72: We plugged this well in the following manner:

1. Set plug at 3215' GLM.
2. Placed 25' cement plug on bridge plug and filled hole back to 1550' w/9.5#/gal mud.
3. Perforated 3 holes @ 1555' GLM.
4. Set cement retainer @ 1505' and pumped 35 sacks cement - leaving cement plug from perforations to retainer. Filled hole to surface w/9.5#/gal mud.
5. Perforated 3 holes @ 630' GLM.
6. Set cement retainer @ 540' GLM and pumped 100 sacks cement - leaving cement plug from perforations to retainer.
7. Set marker in 10 sack cement plug at top of 5 1/2" casing.

*posted
 9-21-73*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles C. Joy TITLE Dist. Supt. DATE 11/9/72

APPROVED BY Julian Morris TITLE OIL AND GAS INSPECTOR DATE SEP 20 1973

CONDITIONS OF APPROVAL, IF ANY: