

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
NM OIL CONS. COMMISSION
DRAWER DDSUBMIT IN TRIPLICATE
(Other Instructions on Reverse)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

LC-065561 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS 88210

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> <u>WIW-TA</u> <u>OCT 7 1982</u>	7. UNIT AGREEMENT NAME <u>Square Lake Flood (East)</u>
2. NAME OF OPERATOR <u>Newmont Oil Company</u>	8. FARM OR LEASE NAME <u>Carper Fed. #B</u>
3. ADDRESS OF OPERATOR <u>P. O. Box 1305, Artesia, N.M. 88210</u>	9. WELL NO. <u>3</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) <u>At surface</u> <u>1980' FNL and 660' FWL of Sec. 34</u>	10. FIELD AND POOL, OR WILDCAT <u>Square Lake (G. SA)</u>
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>Sec. 34-16S-31E</u>
15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>4002' GLM</u>	12. COUNTY OR PARISH <u>Eddy</u>
	13. STATE <u>New Mexico</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)


17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon the above well as follows:

1. Pull tubing and packer.
2. Spot 50 sack cement plug across producing interval in cased hole.
3. Perforate at base of salt 1770', squeeze with 50 sacks cement leaving 100' plug in casing.
4. Perforate at top of salt 760', and squeeze with 50 sacks cement leaving 100' plug in casing.
5. Set 15 sack cement plug at surface down surface and production casing.
6. Erect permanent well marker.

(Note):

- (a) Your office will be notified 24 hrs. prior to operations.
- (b) All plugs will be verified
- (c) Hole will be loaded between all plugs with 10# mud
- (d) We do not plan to pull any casing.



18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

9/29/82

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

OCT 6 1982

FOR

JAMES A. GILHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side