

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
ORIGINAL ON ONE SIDE
REVERSE SIDEForm approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-056302 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS RECEIVED

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> TA - WIW		7. UNIT AGREEMENT NAME Square Lake Flood (Eas)	
2. NAME OF OPERATOR Newmont Oil Company ✓		8. FARM OR LEASE NAME Johnson	
3. ADDRESS OF OPERATOR P. O. Box 1305, Artesia, New Mexico 88210		9. WELL NO. 12	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL, 1980' FEL of Sec. 34		10. FIELD AND POOL, OR WILDCAT Square Lake (G SA)	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4008' GLM	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 34-16S-31E	
		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon the above well as follows:

1. Spot 50 sack cement plug across producing interval in cased hole
2. Perforate at base of salt and squeeze with 50 sacks cement leaving 100' plug in casing
3. Perforate at top of salt and squeeze with 50 sacks cement leaving 100' plug in casing.
4. Set 15 sack cement plug at surface, down surface, and production casing.
5. Erect permanent well marker

Note: (a). Your office will be notified 24 hrs. prior to operations
(b). All plugs will be tagged
(c). Hole will be loaded between all plugs with 10# Mud
(d). We do not plan to pull any casing.

RECEIVED
JUN 18 1982
OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

6/14/82

(This space for Federal Approval)

(Orig. Sgd.) PETER W. CHESTER

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JUN 22 1982

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side