

DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

065561
LC-0605561

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different level.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL ☐ WELL ☐ GAS ☐ WELL ☐ OTHER ☐ TA - WIW JUN 23 1982

2. NAME OF OPERATOR Newmont Oil Company O. C. D.
3. ADDRESS OF OPERATOR ARTESIA, OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

2310' FNL & 1980' FEL of Sec. 34

Square Lake Flood (East)

Johnson

17

Square Lake (G. SA)

Sec. 34-16S-31E

Eddy New Mexico

4027' GLM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon the above well as follows:

1. Spot 50 sack cement plug across producing interval in cased hole
2. Perforate at base of salt and squeeze with 50 sacks cement leaving 100' plug in casing.
3. Perforate at top of salt and squeeze with 50 sacks cement leaving 100' plug in casing.
- * 4. Set 15 sack cement plug at surface, down surface, and production casing.
5. Erect permanent well marker.

Note: (a). Your office will be notified 24 hrs. prior to operations.
(b). All plugs will be tagged
(c). Hole will be loaded between all plugs with 10# Mud.
(d). We do not plan to pull any casing.

* Need cement in annulus behind 5 1/2" casing from at least 50' above to 50' below the 8 5/8" casing shoe. Leave 100' cement plug in 5 1/2" casing across from the 8 5/8" shoe.

RECEIVED
JUN 18 1982
OIL & GAS
GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

6/14/82

(This space for Federal use only)

APPROVED BY: PETER W. CHESTER
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

JUN 22 1982

FOR

JAMES A. GILLHAM

*See Instructions on Reverse Side