

N. M. O. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPI
(Other Instructions
reverse side)TE
re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 029438A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Carper Johnson A

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

Gbr. Jackson, Queen, SA

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 35, T16S, R31E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON ~~WELLS~~ **RECEIVED**(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

APR 15 1975

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

ARWOOD, LTD.

O. C. C.
ARTESIA, OFFICE

3. ADDRESS OF OPERATOR

Petroleum Building, Tower Suite, Roswell, NM 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

860 FSL and 1980 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4036 G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐FULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

8 5/8", 24# set at 743' with 200 sx. (5-29-67)

5 1/2", 14# set at 3880' with 250 sx. (6-6-67) T.D. 3890'

Top of cement @ 2100' from Halliburton Temperature Survey

Perforations 3612-33, 3660-86, 3810-24.

- 1) Spot a 150' cement plug from approximately 3560-3710.
- 2) Shoot casing and spot 100' plug across stub of 5 1/2".
- 3) Spot 100' plug across base of salt at 1860'.
- 4) If stub of pipe is near 1860', use one plug for steps 2 & 3.
- 5) Spot 100' plug across shoe of surface casing.
- 6) Spot 25' plug at surface and marker.

Mud (25 lbs. gel/bbl.) will be utilized between plugs.

RECEIVED

APR 14 1975

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE 4/11/75

(This space for Federal or State office use)

TITLE

DATE

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

APPROVED SUBJECT TO POSSIBLE ADDITIONAL
REQUIREMENT THAT PAD AND/OR ROAD
BE RIPPED AND SEEDED
*See Instructions on Reverse SideCONTACT THIS OFFICE REGARDING ABOVE
---MAKING FINAL CLEANUP.APPROVED
APR 14 1975

L. L. BECK