

c15
up

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87501

AUG 11 1993

O.C.D.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-015-20395
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
2. Name of Operator YATES PETROLEUM CORPORATION		6. State Oil & Gas Lease No.
3. Address of Operator 105 South 4th St., Artesia, NM 88210		7. Lease Name or Unit Agreement Name White BU
4. Well Location Unit Letter F : 2310 Feet From The North Line and 2310 Feet From The West Line Section 14 Township 17S Range 25E NMPM Eddy County		8. Well No. 1
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3508' KB		9. Pool name or Wildcat Eagle Creek San Andres

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Pull rods, pump and tubing.
2. Run 2-3/8" tubing to TD (1457'). Load hole with 10#/gallon brine containing 25#/bbl salt gel.
3. Spot a 25 sack Class "C" 2% CaCl2 plug from 1387-1243' (across perforations). Pull tubing to 700' and circulate hole clean. WOC 4 hours and tag plug.
4. Spot a 25 sack Class "C" plug from 1196-1052' (across 7" shoe). Plug inside + outside casing
5. Spot a 25 sack Class "C" plug from 246' to surface.
6. Cut off wellhead and install regulation abandonment marker.

* Plug 668-768 inside + outside casing

NOTE: NOTIFY NMOC (748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE August 11, 1993

TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE 9/21/93

CONDITIONS OF APPROVAL, IF ANY: