

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a new reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER Plug & Abandon		7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR McClellan Oil Corporation 505-622-3200		8. FARM OR LEASE NAME Hinkle Federal
3. ADDRESS OF OPERATOR P.O. Drawer 730 Roswell, NM 88202-0730		9. WELL NO. #1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FNL & 860' FEL		10. FIELD AND POOL, OR WILDCAT High Nitro Grayburg
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR ARMA Sec 9-T16S-R29E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3702' GL		12. COUNTY OR PARISH Eddy
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	(Other)	<input type="checkbox"/>
(Other) P & A	<input type="checkbox"/>		
PULL OR ALTER CASING	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

8 5/8 csg at 384' Circulated
4 1/2 csg at 2430' w/150 sx cmt
TOC 1550'
2 3/8 EUE

Salt Top 600'
Bottom 740'
Perfs 2362-2370'

1. Set CIBP at 2300' & put 35' cmt on top.
2. Circulate hole w/heavy gel H₂O.
3. Shoot csg off at 1500' & pull csg out of hole.
4. 1st plug at 1550' to 1450' 30 sx (tag)
2nd plug at 790' to 600' 35 sx
3rd plug at 430' to 330' 30 sx (tag)
4th plug at 60' to surface 20 sx

Clean location & install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]

TITLE Drig. & Comp. Engineer

DATE 5-23-91

(This space for Federal or State office use)

APPROVED BY [Signature]

TITLE [Signature]

DATE 6/12/91

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side