

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPL
(Other instructions
verse side)

E*
re-

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-067849

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

HONDO FED GAS COM

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

WILDCAT - WOLF CAMP

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

27-17-27 NMPM

12. COUNTY OR PARISH

EDDY

13. STATE

N.M.

1.

OIL ☐ GAS ☐
WELL WELL OTHER

DRY HOLE

FEB 6 1976

2. NAME OF OPERATOR

AMOCO PRODUCTION COMPANY.

3. ADDRESS OF OPERATOR

BOX 367, ANDREWS, TEXAS 79714

O. C. C.

ARTESIA, OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)
At surface

1980' FSL x 880' FWL Sec. 27 (Unit L. NW/4 SW/4)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3499' R.D. B.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Acidize wolfcamp zone, 6522-32' was perforated w/ 2 ISPF. Acidized w/ 3000 gal 15%. Evaluated. Swab + Pump tested Wolfcamp zones 6522-6711 for appy. On 8-26-75 Imped 80+ OBU in 24 hours. Shut-well in very state.

Propose to P+ A as follows:

- Set CIBP @ 6480' and Cap 35' Cement.

- Set 253x plug from 6100-5850.

- Set 35 Sx "

- Set 50 Sx (100') Across TABO @ 5060-4950 (TABO 5012).
Cement this plug if 5 1/2" Coq is pulled higher than 4950.

- Set 50 Sx (100') 2940-2840 to cover T-Glar. 2890.)

- Set 50 Sx in + out of 8 5/8" CSA 1800. (Plug 1850-1750.)

- Set 10 Sx @ surface and erect P+ A marker.

- All intervals to be filled w/ mud.

Location to be cleaned and levelled.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

ADMINISTRATIVE ASSISTANT

DATE

OCT 20 1975

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

014- USGS-ART
1-DIT
1-SOSP
1-RLI

FEB 5 1976

L. L. BECKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side