

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
N.M. Oil Cons. Division
S. 1st Street
Artesia, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Hanson Operating Company, Inc.

3. Address and Telephone No.

P.O. Box 1515, Roswell, NM 88202-1515

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 28, T.16S, R 30E 330' FSL & 1650 FEL

5. Lease Designation and Serial No.

NM 14900

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Square Lake #2

9. API Well No.

30-015-22031

10. Field and Pool, or Exploratory Area

Square Lake

11. County or Parish, State

Eddy, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Hanson Operating Company, Inc is proposing to plug & abandon the above well in the following manner:

2. 1. Cut off and pull ~~8 5/8"~~^{5 1/2"} casing at 1900' (top of cement), set a 100' cement plug at top of Yates formation. 50' in & out of casing stub - Tag plug.
2. Set a 50' cement plug at surface.
3. set cement plug 100' above perf. at 2830' 2900' - 2800' Tag plug.
4. Remove all equipment, install dry hole marker & restore location. All plugs will be set in place using 9.5# mud laden fluid, all cement plugs will be Class C cement.

3. 100' cement plug 540' - 440' Tag plug.

APPROVED
PETER W. CHESTER

JAN 27 2000

BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA

14. I hereby certify that the foregoing is true and correct

Signed

Betsy Spew

Title

Prod. Analyst

Date

12-9-99

(This space for Federal or State office use)

Approved by

Conditions of approval, if any: ** approved as modified.*

Title

Date