

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088  
RECEIVED

WELL API NO. 300152213800
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 647-320, 647-363, 647-368
7. Lease Name or Unit Agreement Name EMPIRE ABO UNIT "F"
8. Well No. 381
9. Pool name or Wildcat EMPIRE ABO

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator ARCO OIL AND GAS COMPANY ✓
3. Address of Operator BOX 1710, HOBBS, NEW MEXICO 88240	4. Well Location Unit Letter <u>F</u> : <u>1900</u> Feet From The <u>NORTH</u> Line and <u>2260</u> Feet From The <u>WEST</u> Line Section <u>35</u> Township <u>17S</u> Range <u>28E</u> NMPM <u>EDDY</u> County <u></u>
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3679' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☒ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Procedures as follows:

1. MIRU DDP
2. Gave NMOC 24 HR notification of pressure test on csg
3. RIH w/swab to clear tbg
4. Install BOP & POH w/tbg & ACC
5. RIH w/CIBP on tbg
6. Set CIBP @ 6205 RKB
7. POH w/1 jt
8. Pump 105 BBLs 8.6# brine w/2 gal WT 675/10 BF to establish circulation
9. SI Rams on BOP & Press. test to 500#. Install chart
10. If csg holds, POH, laying tbg down. Leave 1 jt on flange
11. If csg doesn't hold, get ahold of Eng. Dept. for further instructions
12. RDCL. Close all tbg, csg, surface csg valves.
13. 4-21-89 Verbal approval by J. Robinson

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James D. Cogburn TITLE Services Supervisor DATE 4-21-89  
TYPE OR PRINT NAME James D. Cogburn TELEPHONE NO. 392-3551

(This space for State Use)

Original Signed By  
Mike Williams

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

Notify NMOC in sufficient time to witness

Pressure Test

MAY 1 1989