

FROM : BEACH EXPLORATION, INC.

PHONE NO. : 915 683 1038

Mar. 08 2002 11:10AM P2

Form C-103

Revised March 25, 1999

Submit 3 Copies To Appropriate District
Office

District I
1625 N. French Dr., Hobbs, NM 88240

District II
1301 W. Grand Ave., Artesia, NM 88210

District III
1000 Rio Brazos Rd., Aztec, NM 87410

District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-015-23000

5. Indicate Type of Lease
STATE ☐ FEE ☐

6. State Oil & Gas Lease No.
L-1603

7. Lease Name or Unit Agreement Name:
Red Lake Unit

8. Well No. 18

9. Pool name or Wildcat
Red Lake, East Queen Grayburg

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Beach Exploration, Inc.

3. Address of Operator
800 North Marienfeld, Ste. 200, Midland, TX 79701

4. Well Location

Unit Letter A : 660 feet from the North line and 660 feet from the East line

Section 35 Township 16S Range 28E NMPM County Eddy

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3588 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☒

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1 RU Well Pluggers

2 POOH w/tubing and packer

3 RIH to 1637', load hole w/10ppg mud

4 Pump 25sx plug (cover 1259' - 1637') (Bottom plug)

5 Tag Bottom plug at 1259' or less. POOH 1460'

6 RIH, perforate 4 1/2" csg at 615', POOH

7 RIH to 615', pump 75sx plug (cover 440' - 615') (Yates & B Salt plug) inside & outside of csg.

8 Tag Yates/B Salt plug at 440'. POOH

9 RIH, perforate 4 1/2" csg at 294', POOH

10 RIH to 294', pump 42sx cmt plug (cover 178' - 294') (Csg shoe & T Salt plug) inside & outside of csg.

11 Tag Csg shoe/T Salt plug at 178'

12 Cutoff wellhead 3' below surface

13 Pump 16sx surface plug in 4 1/2" csg and 8 5/8" x 4 1/2" annulus from surf to 60'

14 Install 4" dry hole marker w/4' above ground w/required info stenciled on pipe

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Lizbeth Lode TITLE Engineering Analyst DATE March 8, 2002

Type or print name Lizbeth Lode

Telephone No. 915-683-6226 ext 12

(This space for State use)

MAR 12 2002