

- a. If commercial perforate additional Morrow from 10,474'-10,491' & 10,511'-10,578' with 4 SPF. May require acid treatment of 2500 gallons 15% NEFE. Continue @ step # 12.
 - b. If non commercial, kill well, pull CA and set CIBP @ 10,590' on wireline. Continue @ step # 10.
10. RIH with CA and spot 15% acetic acid and set packer @ 10,400'. ND BOPE and NU wellhead.
11. Swab tubing down to 3700' and perforate with 1-11/16" strip carriers as in step 9a.
12. Test for production.
13. TOTPS

mu
M. 3