

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different formation.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER DRY HOLE		AUG 10 1982	
2. NAME OF OPERATOR		O. C. D.	
3. ADDRESS OF OPERATOR		ARTESIA, OFFICE	
P.O. Box 1332, Amarillo, TX 79189			
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface		10. FIELD AND POOL, OR WILDCAT	
Eddy County, New Mexico		Wildcat	
Sec 1-16S-28E, 2148 FNL & 990' FWL		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA	
		1-16S-28E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH	13. STATE
	3561 GR	Eddy	New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:


SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>	(Other)	<input type="checkbox"/>		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Load Hole with drilling mud
2. Set cast iron bridge plug at 1100'
3. Dump 20' cement on cast iron bridge plug
4. Spot cement in top of 5 1/2" casing from 33' to 3'
5. Erect dry hole marker and clean up location
6. Left 1186' of 5 1/2" casing in hole.
7. Plug & abandonment - April 1, 1981



18. I hereby certify that the foregoing is true and correct

SIGNED W.E. Rawlings
(This space for Federal or State office use)

TITLE Senior Engineer

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

APPROVED	
DATE	JUNE 23, 1981
JAMES A. GILLHAM DISTRICT SUPERVISOR	

*See Instructions on Reverse Side