

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

OIL CONSERVATION
811 1st ST.
ARTESIA, NM 88210-2834
FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

CENTRAL RESOURCES, INC.

3. Address and Telephone No.

300 West Texas, Suite 830, Midland, TX 79701 915-570-9013

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FNL, 660' FEL, Sec. 4, T16S, R28E

5. Lease Designation and Serial No.

NM-14772

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Coquina Federal No. 1

9. API Well No.

30-015-23744

10. Field and Pool, or Exploratory Area

Diamond Mound Morrow

11. County or Parish, State

Eddy County, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Current well status is presented on the attached wellbore sketch.

Plug as follows:

1. Pull out of hole w/ tubing.
2. Set cement retainer 5,300' to pump 300 sacks class "C" cement.
3. Cut 4 1/2" casing @ 2,000' and pull out of hole.
4. Spot 75 sacks cement from 2,050' up to 1,775' with tubing.
5. Spot 35 sacks cement from 645' up to 525' with tubing.
6. Set 10 sack cement plug at surface.
7. Cut casing and remove wellheads 6' below ground level and weld up marker with well identification.
8. Remove equipment and remediate location to acceptable standards.

Note: a) mud laden fluid will be left between all plugs.
b) if casing cannot be pulled, a retainer/packer will be used to squeeze plug in place.

14. I hereby certify that the foregoing is true and correct

Signed Rodney L. Seale

Title Rodney L. Seale, Superintendent

Date 11/27/95

(This space for Federal or State office use)

Approved by (ORIG. SCD.) JOE G. LARA

Title PETROLEUM ENGINEER

Date 1/16/96

Conditions of approval, if any: See attached. Also tag plug @ sty 2 #4.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statement or representation as to any matter within its jurisdiction.

Abandonment: See instruction on Reverse Side