Form 3160-5 (June 1990)

U ED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

N.M. Oil ns. Division 811 S. 1st Street

CISF

BUREAU OF LAND MANAGEMENT Artesia, NM 88210-2834 FORM APPROVED

	i ilitarial titure a see	Expires March 31, 1993
SUNDRY NOTICES AND REPORTS ON WELLS		5. Lease Designation and Serial No.
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.		LC-057798
Use "APPLICATION FOR PERMIT—" for such proposals		6. If Indian, Allottee or Tribe Name
SUBMIT IN TRIPLICATE		NA .
031-12		7. If Unit or CA, Agreement Designation
1. Type of Well ☐ Gas ☐ Other Well Other	128 29 30 CT 2 3 Page	8. Well Name and No.
2. Name of Operator DEVON ENERGY CORPORATION (NEVADA)		Logan 35 Federal #14
3. Address and Telephone No.		9. API Well No.
20 NORTH BROADWAY, SUITE 1500, OKLAHOMA CITY, OKLAROMA 73102 74 235-3614		30-015-30736
4. Location of Well (Footage. Sec., T., R., M., or Survey Description)		10. Field and Pool, or Exploratory Area
4. Location of Well (Footage. Sec., T., R., M., or Survey Description) 330' FSL & 500' FWL, Section 35-17S-27E, Unit "M"		Red Lake; Glorieta-Yeso, NE
335 1 5 Z d 365 1 11 Z d 365 1 1 1 Z d 365 1 1 1 2 1 Z d 365 1 Z d 3		11. County or Parish, State
		Eddy County, NM
CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
TYPE OF SUBMISSION TYPE OF ACTION		
TIPE OF SUBMISSION		
Notice of Intent	Abandonment	Change of Plans
C.L. S.L.	Recompletion Plugging Back	New Construction Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing	Conversion to Injection
	Other Perf & stimulate San Andres & downhole of	commingle w/ Yeso Dispose Water
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
Devon Energy Corporation (Nevada) plans to perforate and stimulate the San Andres and downhole commingle with the Yeso as follows: TOH w/ rods & pump. ND wellhead, NU BOP. TOH w/ tbg. PU CIBP & TIH on tbg, set CIBP @ ±3000'. Test CIBP to 1000 psi. Perf San Andres @ 2743'-2872'. Acidize San Andres. Frac down csg. TIH w/ RBP on tbg & set @ ±2600'. Test RBP to 1000 psi. Perf San Andres @ 2000'-2423'. Acidize & frac San Andres down csg. Retrieve RBP. Run pumping equipment & pump test until production stabilizes. After well pumps down, drill		
out CIBP & commingle production from the San Andres and Yeso (currently in the process of filing a downhole		
commingling application with the NMOCD).		
0 0 11	,	
14. I hereby certify that the foregoing is true and correct		
1 1/ 1/ 1/	Tonja Rutelonis	
Signed Whip Latelow	Title Engineering Technician	Date 3/8/00
(This space for Federal or State office use)		
(ORIG SGD.) ALEXIS C SWO	BODA Title PETROLEUM ENGINEER	MAR 3 0 2000
Approved by	Title PETROLEUM ENGINEER	Date
Conditions of approval, it airy.		

BOSWELL, NM

MAR 27 2000

BECEINED