

UNITED STATES DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
Alameda, NM 88210

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Phillips Petroleum Company

3. ADDRESS OF OPERATOR

4001 Penbrook St., Odessa, Texas 79762

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

Unit I, 1980' FSL & 660' FEL

14. PERMIT NO.

API No. 30-015-03123

15. ELEVATIONS (Show whether D., ST., GR., etc.)

3578' RKB

RECEIVED BY  
SEP - 5 1986  
O. C. D.  
ARTESIA, OFFICE

5. LEASE DESIGNATION AND SERIAL NO.

LC-028784-b

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

C/SF

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Keely B Federal

9. WELL NO.

10

10. FIELD AND POOL, OR WILDCAT

Gb-J-SR-Q-Gb-SA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

26, 17-S, 29-E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to Water Injector

PCLL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Recommended procedure to convert well to water injection:

1. MI & RU DDU.

2. COOH with rods and pump. Install BOP. COOH with tubing. GIH with 6-1/4" bit and casing scraper on 2-3/8" work string. Drill out cement and CIBP, clean out as required to original TD of 3166'.

3. COOH with tubing, scraper and bit.

4. GIH with 7" RTTS-type packer on 2-3/8" work string. Set packer at  $\pm 2380'$ . Pressure annulus to 500 psi for 15 minutes to verify casing integrity. If casing does not hold pressure, reset packer up hole and retest annulus. Should casing fail to hold pressure, casing inspection log will be run.

5. Release packer, GIH and set packer at  $\pm 2900'$ .

\*\*See attached pages for additional procedure\*\*

18. I hereby certify that the foregoing is true and correct

SIGNED

W. J. Mueller

TITLE Engr. Supv., Resv.

DATE August 27, 1986

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

9-4-86

Subject to  
Like Approval  
by State

\*See Instructions on Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

6. MI \_\_\_\_\_ treating company. Phillips supervisor will hold safety meeting with treating company personnel. RU to acidize the San Andres open hole interval with 2,500 gallons of 15% NEFE HCl containing clay stabilizer. Load annulus with produced water and monitor level in annulus during treatment. Pressure test all lines to 5,000 psi before starting treatment. Keep treating pressure as low as possible, maximum treating pressure 5,000 psi. Treat at 4-5 BPM as follows:
  - a. Open circulating valve and displace tubing with 450 gallons of acid. Close circulating valve.
  - b. Pump 1,050 gallons acid.
  - c. Pump 250 gallons 10 ppg brine containing 1.5 lb/gal graded rock salt.
  - d. Pump 1,000 gallons acid.
  - e. Flush with 25 bbls of 2% KCl water.
7. Flow and swab back acid and load water (total volume is 90 bbls).
8. COOH with tubing and packer.
9. GIH with packer-type RBP and RTTS-type packer on tubing. Set RBP at +2,900'. Set packer at +2,890 and test RBP to 1,000 psi. Release packer.
10. Spot 18 bbls of 10% acetic acid from 2,880' to 2,430'. COOH with tubing and packer.
11. MI \_\_\_\_\_ wireline company. Phillips supervisor will hold safety meeting with wireline company personnel. Run Gamma Ray/Collar Locator log from TD 3,166' to 2,200'. RU to perforate 7" casing using 4" OD casing gun loaded with deep penetrating DML charges, 2 shots/ft, spiral shot phasing. Perforate as follows top to bottom:

2,436' - 2,442'	6 feet	12 shots
2,500' - 2,502'	2 feet	4 shots
2,656' - 2,660'	4 feet	8 shots
2,719' - 2,723'	4 feet	8 shots
2,733' - 2,735'	2 feet	4 shots
2,773' - 2,775'	2 feet	4 shots
2,817' - 2,819'	2 feet	4 shots
2,836' - 2,838'	2 feet	4 shots
2,865' - 2,867'	2 feet	4 shots
TOTAL	26 feet	52 shots

Note: Casing collars are located at 2,461', 2,493', 2,523', 2,553', 2,581', 2,611', 2,642', 2,673', 2,706', 2,736', 2,766', 2,793', and 2,824' from Dresser Atlas VDL/GR/Cement Bond Log run 9/21/82.

---

step. GIH with 7" Baker Model AD-1 (or equivalent) plastic coated injection packer on plastic coated 2-3/8", 4.7#/ft, J-55 8rd EUE tubing. Displace tubing-casing annulus with 2% KCl water containing 1% by volume of Techni-hib 370 (packer fluid). Set packer at +2,380' in 10,000 lbs tension. Pressure test casing to 500 psi for 15 minutes; use two-pen recorder to record tubing and casing pressure during test.

Note: Packer should have shear ring installed to allow the packer to be released by shearing with +25,000 lbs tension.

17. Remove BOP, install wellhead injection assembly, and place well on injection. Do not exceed 485 psi surface injection pressure.