

**NMOCC COPY**

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

*Copy to S.F.*  
Approved  
Budget Bureau No. 42-R1424

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER Water Injection ☒ **RECEIVED**

2. NAME OF OPERATOR  
Shenandoah Oil Corporation **MAR - 3 1978**

3. ADDRESS OF OPERATOR  
P.O. Box 1027, Odessa, Texas 79760 **G. C. C.**

4. LOCATION OF WELL (Report location clearly and in accordance with any State ~~mining~~ **mining** office.  
See also space 17 below.)  
At surface  
1980 FNL & 1980 FEL Section 27, T-17-S, R-29-E,  
Eddy County, New Mexico

5. LEASE DESIGNATION AND SERIAL NO.

LC028775 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Robinson-Jackson Unit

8. FARM OR LEASE NAME

Tract 2

9. WELL NO.

15

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 27, T-17-S, R-29-E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3548 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☐

WATER SHUT-OFF ☐

REPAIRING WELL ☐

FRACTURE TREAT ☐

MULTIPLE COMPLETE ☐

FRACTURE TREATMENT ☐

ALTERING CASING ☐

SHOOT OR ACIDIZE ☐

ABANDON\* ☐

SHOOTING OR ACIDIZING ☐

ABANDONMENT\* ☐

REPAIR WELL ☒

CHANGE PLANS ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Pull tubing and packer
2. Set drillable CIBP at approximately 2300'.
3. Perforate 2 holes for squeeze at approximately 1760' and perforate 2 holes for squeeze at 1260'.
4. Set cement retainer at approximately 1700' and cement. Set cement retainer at approximately 1200' and cement.
5. Drill out retainers, cement and CIBP.
6. Run packer and tubing and put back on injection.

**RECEIVED**  
**MAR 2 - 1978**  
**U.S. GEOLOGICAL SURVEY**  
**ARTESIA, NEW MEXICO**

18. I hereby certify that the foregoing is true and correct

SIGNED *C. M. Downey*

TITLE Division Manager

DATE 2-27-78

(This space for Federal or State office use)

APPROVED BY *John J. Lane*

TITLE ACTING DISTRICT ENGINEER

DATE MAR 3 - 1978

CONDITIONS OF APPROVAL, IF ANY: