

Form 3160-5
(July 1989)
(Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVED
OFFICE FOR NUMERICAL
OF COPIES REQUIRED
(Other instructions on reverse
side)
RECEIVED

BLM Roswell District
Modified Form No.
NM060-3160-4

4518

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. LC-028775-B	
2. NAME OF OPERATOR Southland Royalty Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME CONS. COMMISSION	
3. ADDRESS OF OPERATOR P.O. Box 51810, Midland, TX 79710-1810		7. UNIT AGREEMENT NAME Robinson Jackson Unit	
3a. AREA CODE & PHONE NO. (915)688-6800		8. FARM OR LEASE NAME RJU Tract 1A	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 440' FNL & 440' FEL		9. WELL NO. 2	
10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7R,QN		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 34, 17S, 29E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) UNK GL	12. COUNTY OR PARISH Eddy	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

☐
☐
☒
☐

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

☐
☐
☐

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

MIRU. POH w/rods and pump. LD same. Install BOPE. POH w/2-3/8" tubing.
RIH w/2 7/8" tubing and bit to +/-3150'. Circulate hole w/10ppg brine mud. PUH w/2 7/8" tubing to +/-2500'. RU cementing equipment and lay 35 sxs Class C cement plug from 2500' to 2365'. POH. Wait 4 hours. RIH and tag same.
RU casing lift sub on 8 1/4" casing. RIH w/jet cutter and cut casing @ +/-960'. POH w/jet cutter.

POH w/8 1/4" casing. LD same.

RIH open end w/2 7/8" tubing to 1010'(50' inside casing stub). Lay 70 sxs Class C w/2% CaCl cement plug f/1010' to 848'. POH. Wait 4 hours and tag. Pressure test casing to 500 psi.

RIH w/4" casing gun and perforate 10" casing from 760'-761' w/4 jhpf (8 holes). POH.

RU on 10" casing establish circulation down casing. Displace hole with fresh water. Mix and pump 50 sxs Class C cement. Displace same with 72 bbls gelled brine and wiper plug.

RIH w/4" casing gun and perforate 10" casing @ 360'-361' w/4 JHPF (8 holes).

Establish circulation down 10" casing. Mix and pump 130 sxs Class C cement and displace same w/26 bbls of gelled brine mud. Circulate to surface. RIH w/2 7/8" tubing to 50'. Mix and pump 32 sxs Class C cement and circulate same to surface. Cut off casing 3' below surface and place abandonment maker as per regulations.

Restore location as directed.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Production Asst.

DATE

(This space for Federal or State office use)

APPROVED BY

(ORIG. SGD) DAVID R. GLASS

CONDITIONS OF APPROVAL, IF ANY:

DATE

SEE ATTACHED

*See Instructions on Reverse Side