

Form 3160-5
(July 1989)
(Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVED
OFFICE FOR NUMBER
OF COPIES REQUIRED
(Other instructions on reverse
side)

BLM Roswell District
Modified Form No.
NM060-3160-4

CSF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> WIW		5. LEASE DESIGNATION AND SERIAL NO. LC-028775-B	
2. NAME OF OPERATOR Southland Royalty Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME COMMISSION	
3. ADDRESS OF OPERATOR P.O. Box 51810, Midland, TX 79710-1810		7. UNIT AGREEMENT NAME Robinson Jackson Unit	
3a. AREA CODE & PHONE NO. (915)688-6800		8. FARM OR LEASE NAME RJU Tract 2	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FSL & 1980' FWL		9. WELL NO. 17	
10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7R,QN		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec35, 17S, 29E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3542' GL	12. COUNTY OR PARISH Eddy	13. STATE NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

MIRU Release packers. POH. RIH w/2 7/8" tubing, bit and scraper to 3130'.

RIH w/7"-20# CICR and set @ 3120'. Test tubing to 1500 psi. Cement sq. Grayburg Jackson open hole interval w/50 sxs Class C. Pull out of retainer and dump 6 sxs Class C atop same. Displace hole w/10ppg gelled brine.

RIH w/7" CIBP and set @ 2490'. Lay 25 sxs Class C CMT atop same.

RIH w/4" casing gun and perforate from 900'-901' w/4JHPF. RIH w/7" CICR and set @ 850'. Test tubing to 1000 psi. Cement w/30sxs Class C below retainer. Drop 6 sxs Class C atop same.

RIH w/4" casing gun and perforate 550'-551' w/4 JHPF.

Establish circulation down 7" casing. Displace hole w/fresh water. Mix and pump 150 sxs Class C cement and circulate to surface.

Cut off casing 3' below surface and place abandonment maker as per regulations.

Restore location as directed.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

PRODUCTION ASSISTANT

DATE

6/22/93

(This space for Federal or State office use)

APPROVED BY

TITLE

(ORIG. SGD) DAVID R. GLASS

DATE

CONDITIONS OF APPROVAL, IF ANY:

SEE ATTACHED

*See Instructions on Reverse Side