

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

REVISED

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER ☐

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter N : 330 Feet From The South Line and 2310 Feet From The West Line

Section 36 Township 17S Range 29E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

WELL API NO.

30-015-03801

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

B-1778-20

7. Lease Name or Unit Agreement Name

WLHU G4S Unit Tract

8. Well No.

23-1

9. Pool name or Wildcat

Loco Hills Queen-GB-San Andres

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NOTIFY OCD-ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING
Propose to plug and abandon as follows:

1. TOOH with 2-7/8" tubing

2. TIH and set CIBP at 2600'. TIH with tubing and tag CIBP. Load hole with plugging mud. Spot a 30 sack Class C cement plug from 2600-2450'.

3. TOOH with tubing. TIH with casing gun and perforate 7" casing with 6 holes at 1150' and 6 holes at 350'.

4. Set cement retainer at 1100' (wireline set). TOOH. TIH with tubing and load hole with plugging mud. Sting into retainer and establish injection rate. Mix & pump 75 sacks Class C cement to squeeze. Leave 35' of cement on top of retainer. TOOH with tubing.

5. TIH with cement retainer and set at 275' (wireline set). TOOH. TIH with tubing. Load hole with plugging mud. Sting into retainer and establish circulation. Mix & pump 100 sacks of Class C cement from 350-135' to squeeze. Sting out of retainer. Spot 30 sacks of Class C cement on top of retainer. TOOH with tubing.

6. Spot a 15 sack Class C cement plug at surface.

7. Install regulation abandonment marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Rusty Klein

TITLE

Operations Technician

DATE Jan. 21, 2000

TYPE OR PRINT NAME

Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY

Mike Steelfield

TITLE

Field Rep. II

DATE 2/8/2000

CONDITIONS OF APPROVAL, IF ANY:

* Notify NMOCN to witness Plugging Operations.