

NO. OF COPIES RECEIVED	6
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	4

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

FEB 5 1968

O. C. C.
ARTESIA OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.
B-1778

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> Water Injection Well	7. Unit Agreement Name Free Hill
2. Name of Operator Newmont Oil Company ✓	8. Form or Lease Name State "A"
3. Address of Operator P. O. Box 1305, Artesia, New Mexico - 88210	9. Well No. No. 3
4. Location of Well UNIT LETTER 0, 1295 FEET FROM THE South LINE AND 2615 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 17S RANGE 29E NMPM.	10. Field and Pool, or Wildcat Loco Hills Grayburg
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
-------------------------	-----------------------

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug and abandon the water injection well by:

1. Set 25 sack cement plug at 2620-2771'.
2. Pull all 4 1/2" casing possible (expect to recover 2200')
3. Set 25 sack cement plug at top of 4 1/2" stub
4. Set 25 sack cement plug at 1020'
5. Set 25 sack cement plug at 440-510'
6. Pull all 8 5/8" casing possible
7. Set marker at surface with 5 sacks of cement
8. Clean and level location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James L. DeLuette TITLE Division Superintendent DATE 2/2/68

APPROVED BY W. A. Gressett TITLE Division Superintendent DATE 2/2/68

CONDITIONS OF APPROVAL, IF ANY: Intervals between plugs filled with mud.