

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**RECEIVED CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

SEP 11 '89

O. C. D.

WELL API NO.	NA
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	B-2209
7. Lease Name or Unit Agreement Name	Etz "A" State
8. Well No.	2
9. Pool name or Wildcat	Grayburg Jackson

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☐ OTHER ☒ Injection

2. Name of Operator Devon Energy Corporation

3. Address of Operator 1500 Mid-America Tower  
20 N. Broadway, Okla. City, Okla. 73102-9951

4. Well Location

Unit Letter L : 1980 Feet From The South Line and 660 Feet From The West Line

Section 16 Township 17-S Range 30-E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3667' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8/24/89 Rig up Baber Well Service, pull 2 3/8" tubing & Packer, RIH, spot 75 sks. cement @ 2058'. Tagged plug @ 2019'.  
8/25/89 Load 7" csg. with mud from 2019' back to 1040', spot 10 sks. cement. Perf. 2 holes @ 1040'. RIH, set packer @ 780', pumped into perfs, spot 25 sks. cement, leaving 100' cement inside & 100' cement outside 7" csg.  
8/28/89 POH w/ tubing & packer, RIH w/ wireline, tagged cement @ 905'. RIH w/ tubing, load hole with mud from 905' back to 430'. POH w/ tubing, perforate 2 holes @ 430'. RIH w/ tubing & packer, set packer @ 240', pumped 80 sks. cement through perfs. @ 430', back to surface between 7" & 8 1/4" csg. W.O.C. 2 hours. Tagged plug @ 300'. Load hole with mud, spot 15 sks. cement from 90' back to surface.  
8/29/89 Cut off wellhead, install P & A marker, cleaned up location, moved off.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Roy D. Henson TITLE Area Foreman DATE 9/7/89

TYPE OR PRINT NAME Roy D. Henson TELEPHONE NO 915-943-3952

(This space for State Use)

APPROVED BY Danell Moore TITLE Geologist DATE 10/19/89

CONDITIONS OF APPROVAL, IF ANY:

Post ID-2  
9-15-89  
PFA