

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

SEP 11 '89

O. C. D.

WELL API NO. NA
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1483

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ OTHER ☒ Injection

2. Name of Operator
DEVON ENERGY CORPORATION

3. Address of Operator 1500 Mid-America Tower, 20 N. Broadway
Oklahoma City, Okla. 73102-9951

4. Well Location
Unit Letter J 2310 Feet From The South Line and 660 Feet From The West Line

Section 16 Township 17 S Range 30 E NMMP Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3667' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. 8/14/89 Rig up Baber Well Service. Could not unseat packer. SDON 3/15/89 Packer @ 1974'. Shot tbq. off @1954'. Could not pull tbq. Shot tbq. off @1600', above free point @ 1615'. RIH w/ tbq., spot 25sx cement, POH, pick up packer at packer @1209', squeeze cement through tbq. @1600". P.O.H. Shut down overnight. 8/16/89 Tag plug @ 1542'. Perforate @ 1066'. RIH w/packer to 712', press csg. to 500#. Held O.K. Lay down packer, RIH w/tbg. to 1542', load hole w/mud to 600', pull up to 1120', spot 25 sks cement, pull up to 630', spot 25 sks. WOC 2 hrs. Tag plug @ 512'. Perf. 2 holes @ 430'. RIH w/tbg. to 470', spot 25 sks. cement. SDON. 8/17/89 Tag plug @ 490'. Spot 25 sks. cement @ 470'. WOC 2 hrs. Tag plug @ 450' spot 25 sks. @ 441'. WOC 2 hrs. Tag plug @ 410'. RIH w/tbg. to 378', load hole w/mud, pull up @spot 15 sks. cement from 90' to surface. 8/29/89 Install P/A marker, clean location. 3 1/4" csg. @ 465'; 6 5/8" csg. @1870'; 4 1/2" Liner 1825'-2078' T.D. 2084'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Roy D. Henson TITLE Area Foreman DATE 9/1/89

TYPE OR PRINT NAME Roy D. Henson TELEPHONE NO. 915-943-3952

(This space for State Use)

APPROVED BY Danell Moore TITLE Geologist DATE 11/1/89

CONDITIONS OF APPROVAL, IF ANY:

Post ID-2
9-15-89
PFA