

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)

Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO  
LC 028936-g

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Brigham

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Loco Hills-Q-G-SA

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Unit P, Sec. 31-17S-30E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED BY

MAR 27 1987

O. C. D.

ARTESIA OFFICE

1. OIL WELL ☐ GAS WELL ☐ OTHER P&A - WIW

2. NAME OF OPERATOR

Yates Petroleum Corporation

3. ADDRESS OF OPERATOR

105 South 4th St., Artesia, NM 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

330 FSL & 990 FEL, Sec. 31-T17S-R30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

AMENDED P&A PROPOSAL.

Propose to plug well as follows:

1. Spot 35 sx cement plug (180') on existing bridge plug at 2617'.
2. Isolate Queen formation from overlying zones with 100' cement plug. Top of Queen is at 2321'; top of cement is at 1453'.
3. Perforate 50' below base of salt at 1225' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
4. Perforate 50' above top of salt at 390' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
5. Set 50' surface plug both sides of casing and install regulation abandonment marker.

NOTE: NOTIFY BLM, CARLSBAD, NM (887-6544) 24 HOURS PRIOR TO BEGINNING WORK.

Mud between plugs to be 10#/gallon mud-laden fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED

Albert R. Hall

TITLE

Engineer

DATE

3-20-87

(This space for Federal or State office use)

Orig. Sgd. Und.

APPROVED BY

TITLE

DATE

3-25-87

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side