

DISTRICT I

State of New Mexico
Energy, Minerals and Natural Resources Department

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-04428

5. Indicate Type of Lease
State ☒ FEE ☐

6. State Oil & Gas Lease No.
B-4108

7. Lease Name or Unit Agreement Name
SCHEURICH A

8. Well No.
1

9. Pool Name or Wildcat
LOCO HILLS QUEEN GRAYBURG, SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE " APPLICATION FOR PERMIT
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL ☐ GAS ☐
WELL ☒ WELL ☐ OTHER ☐

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South 4th., Artesia, NM 88210

4. Well Location
Unit Letter E : 2310 Feet From The NORTH Line and 330 Feet From The WEST Line
Section 32 Township 17S Range 30E NMPM EDDY COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>		OTHER <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION proposes to plug & abandon as follows:

Notify OCD 24 hrs. prior to any work done

MIRU - No casing recovery will be attempted. Toh w/ 2-7/8" tubing.

RU wireline; TIH & set 5-1/2" CIBP @ 2555'; TOH. TIH w/ tubing, tag CIBP, load hole w/ plugging mud.

Keep wellbore loaded w/ mud. Spot 40 sack Class C Cement plug from 2406-2555' on top of CIBP - this will also cover 5-1/2" casing stub @ 2456'. -TA9

TOH w/ tubing. RU wireline to perforate 7" casing w/ casing guns - 6 shots @ 1200' & 603'.

TIH w/ wireline; set cement retainer @ 1150'; TOH. TIH w/ tubing, load hole w/ plugging mud; sting into retainer and establish injection rate. Squeeze w/ 75 sx Class C cement. Leave 35' of cement on top of retainer. TOH w/ retainer. TOH w/ tubing.

ND BOP; TIH w/ wireline, set retainer @ 503'; TOH. TIH w/ tubing & load hole w/ plugging mud. Sting into retainer and establish injection rate. Squeeze w/ 60 sx Class C cement w/ 5#/sx salt from 503-603'; leave 35' of cement on retainer. TOH w/ tubing. *Surface Plug must be placed inside & outside of 8 1/4" & 7" CS9.*
Spot 100' Class C cement plug @ surface. Remove all surface equip. & weld on regulation marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Donna Clack TITLE Operations Technician DATE 3/11/02

TYPE OR PRINT NAME DONNA CLACK TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE MAR 15 2002

CONDITIONS OF APPROVAL, IF ANY