

qsf
BP

State of New Mexico
Energy, Minerals and Natural Resources Department

DISTRICT I

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-015-04437
5. Indicate Type of Lease	State <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	B-4108
7. Lease Name or Unit Agreement Name	SCHEURICH
8. Well No.	4
9. Pool Name or Wildcat	LOCO HILLS QUEEN GRAYBURG, SA

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL ☐ GAS ☐
WELL ☒ WELL ☐ OTHER ☐

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South 4th., Artesia, NM 88210

4. Well Location
Unit Letter k : 2525 Feet From The SOUTH Line and 1435 Feet From The WEST Line
Section 32 Township 17S Range 30E NMPM EDDY COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION proposes to plug & abandon as follows: Notify OCD 24 hrs. prior to any work done

MIRU - No casing recovery will be attempted. TOH w/ 2-3/8" tubing.

TIH w/ 2-3/8" tubing open-ended; attempt to get to 583' & set 3 1/2 sack cement plug w/ 2% CaCl₂ plug from 583' - 585'. Pull tubing up hole & circ clean. WOC 2-1/2 hours & tag plug. Re-set if necessary. inside? outside of CS?

Load hole with plugging mud. Set 3 1/2 sk cement plug w/ 2% CaCl₂ from 187' - 187'. Pull tubing up hole & circ clean. WOC 2-1/2 hrs & tag plug. Re-set if necessary. POH.

RU wireline to perforate 5-1/2" casing w/ 4 holes @ 1221' & 552'.

Trip in hole w/ wireline to set cement retainer @ 1121'; TOH. TIH w/ tubing; load hole w/ plugging mud, sting into retainer & establish injection rate. Squeeze w/ 75 sx Class C cement. Leave 35' cmt on top of retainer; TOH.

ND BOP; TIH w/ wireline, set cement retainer @ 452'. TOH. TIH w/ tubing, load hole w/ plugging mud, sting into retainer & establish circ. Squeeze w/ 60 sx Class C cement w/ 5#/sx salt from 452'-552'; leave 35' of cement on retainer - TOH.

Spot 100' 60' Class C cement plug @ surface. Surface plug must be inside? outside of 5 1/2" & 8 1/4" es.

Remove all surface equipment & weld regulation dry hole marker.

I hereby certify that the information above a true and complete to the best of my knowledge and belief.

SIGNATURE Donna Clack TITLE Operations Technician DATE 3/11/02

TYPE OR PRINT NAME DONNA CLACK TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE MAR 15 2002

CONDITIONS OF APPROVAL, IF ANY