## DEPARTMENT OF THE INTERIOR (Other Instruction verse side)

CATE\*

Form approved. Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO. 6. IF INDIAN, ALLOTTEE OR TRIBE NAME

LC 029395 (a)

GEOLOGICAL SURVEY					
SUNDRY	NOTICES	AND	REPORTS	ON	WELLS

(Do not use this form for proposal Use "APPLICAT:	s to drill or to deepen or plug     ION FOR PERMIT—'' for such p	back to a different reservoir. roposals.)		•	
OIL X GAS OTHER		RECEIV	ED	7. UNIT AGREEMENT NAS	ME
2. NAME OF OPERATOR				8. FARM OR LEASE NAM	E
Atlantic Richfield Company	7 1	MAR 3 197	S	Turner "A"	
3. ADDRESS OF OPERATOR		men o 197	<del>''</del>	9. WELL NO.	<u> </u>
P. O. Box 1710, Hobbs, Ne		Ĭ.		21	
<ol> <li>LOCATION OF WELL (Report location clesses also space 17 below.)</li> <li>At surface</li> </ol>	rly and in accordance with any	State requirements	Œ	10. FIELD AND POOL, OR Fren Seven Riv	
2310' FNL & 2310' FEL (Unit letter G)			111. SEC., T., R., M., OR BLK. AND SURVEY OR AREA		
				19-T17S-R31	E
14. PERMIT NO.	. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)			12. COUNTY OR PARISH	13. STATE
	3614 GL			Eddy	N.M.

16.

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTERIOR TO.		SUBSEQUENT REPORT OF.		
Γ-	<del></del>			<del></del> 1
TEST WATER SHUT-OFF	PULL OR ALTER CASING		WATER SHUT-OFF	REPAIRING WELL
FRACTURE TREAT	MULTIPLE COMPLETE		FRACTURE TREATMENT	ALTERING CASING
SHOOT OR ACIDIZE	ABANDON*		SHOOTING OR ACIDIZING	ABANDONMENT*
REPAIR WELL	CHANGE PLANS		(Other)	
(Other) Plug	& abandon	X	(NOTE: Report results of mu Completion or Recompletion F	ltiple completion on Well Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

TD 1932'. PBD 1917'. Completed in OH interval 1855-1917'.

8-5/8" OD csg set @ 500' & cmtd w/30 sx.

 $5\frac{1}{3}$ " OD 14# csg set @ 1855' & cmtd w/75 sx.

This well is depleted in the Fren SevenRivers zone and is not needed in the future for Fren Sand waterflood. Propose to P&A in the following manner:

- 1. Rig up, install BOP.
- 2. Run 2-3/8" OD EUE tbg OE to 1755' & spot 30 sx Cl C cmt to cover bottom 100' of  $5\frac{1}{7}$ " csg.
- 3. Fill hole w/heavy gelled mud between all cmt plugs.

- 4. Run free point on 5½" OD csg. Cut csg from free point @ approx 1300' & pull.
  5. Spot 35 sx Cl C cmt (100' plug) across 5½" csg stub.
  6. Spot 35 sx Cl C cmt (100' plug) across 8-5/8" OD csg shoe & top of salt @ 500'.
- 7. Spot 10 sx Cl C cmt @ surface. Install regulation dry hole marker, clean & level location.

RECEIVED

NOV 25 1975

ARTESIA NEW MEXICO

	DIVINA NEW MEXICO			
18. I hereby certify that the foregoing is true and correct	* ****			
SIGNED To Kay Fre.	TITLE Dist. Drlg. Supv.	DATE 11/24/75		
(This space for Federal or State office use)				
APPROXED BY TED CONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE		
MAR - 2 15 Th				

\*See Instructions on Reverse Side