

O+5 - USGS-P.O. Box 1857  
Roswell, NM 88201

1 - Engr.  
1 - Foreman  
1 - NM OFFICER  
Drawer DD  
Artesia, NM 88210

1 - NMOCDD - Drawer DD, Artesia, NM  
88210

Form 9-331  
Dec. 1973

Form Approved.  
Budget Bureau No. 42-R1424

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil  gas  other Injection well

2. NAME OF OPERATOR  
Getty Oil Company /

3. ADDRESS OF OPERATOR  
P.O. Box 730 Hobbs, NM 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1980 FSL & 1980 FEL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:


16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- TEST WATER SHUT-OFF
- FRACTURE TREAT
- SHOOT OR ACIDIZE
- REPAIR WELL
- PULL OR ALTER CASING
- MULTIPLE COMPLETE
- CHANGE ZONES
- ABANDON\*
- (other)

SUBSEQUENT REPORT OF:

- 
- 
- 
- 
- 
- 
- 
- 



(NOTE: Report results of multiple completion or zone change on Form 9-330.)

OIL & GAS  
U.S. GEOLOGICAL SURVEY  
ROSWELL, NEW MEXICO

5. LEASE  
LC-029418 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
REC-10

7. UNIT AGREEMENT NAME  
Skelly Unit

8. FARM OR LEASE NAME  
Skelly Unit

9. WELL NO.  
71

10. FIELD OR WILDCAT NAME  
Grayburg/Jackson SR-Q-G-SA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec 23, T17S R31E

12. COUNTY OR PARISH  
Eddy

13. STATE  
NM

14. API NO.  
3686' DF

15. ELEVATIONS (SHOW DF, KDB, AND WD)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Rig up pulling unit.
2. Install BOP.
3. RIH w/bit and drill out bridge plug.
4. RIH w/cement retainer & set @ ± 3200 ft. & squeeze w/100 sks cement. Fill hole w/mud to 1750'.
5. POH w/tubing.
6. RIH & perf two squeeze holes @ 1750'.
7. RIH w/pkr. & set @ ± 1700' & squeeze w/35 sks of cement. Fill hole w/mud to 675'.
8. RIH and perf two squeeze holes @ 675' and squeeze w/35 sks cement. Fill hole w/mud to surface.
9. Set a surface plug & dry hole marker w/25 sacks.

10. Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Dale R. Crockett TITLE Area Superintendent DATE 1/7/82

APPROVED AS AMENDED

APPROVED (Only Sign) PETER W. CHESTER TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

FEB 25 1982

JAMES A. GILLHAM  
DISTRICT SUPERVISOR

\*See Instructions on Reverse Side

45F

H7