

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE  
(Other instructions on the  
reverse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 555569

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/> Injection		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR DeltaUS Corporation		8. FARM OR LEASE NAME Green Federal	
3. ADDRESS OF OPERATOR 3100-C North A Street Midland, Texas 79705		9. WELL NO. 7	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface  Unit B, 990' FNL and 1650 FEL, Section 31, T-17-S, R-29-E		10. FIELD AND POOL, OR WILDCAT Artesia QGSA	
14. PERMIT NO.		11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA 31 T-17S, R-29E	
15. ELEVATIONS (Show whether DP, RT, GR, etc.) 3635' GL		12. COUNTY OR PARISH Eddy	
		13. STATE NM	

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Prep to PXA as follows:

1. RIH w/workstring to 2630' (PBSD). Spot 30 sx plug from PBSD -2420'
2. RIH and perf 1 hole at 1610'. Pump 100' plug inside and outside (50 sx). Plug will extend from 1610-1510'.
3. RIH and perf 1 hole at 900'. Pump 100' plug inside and outside (50 sx). Plug will extend from 900'-800'.
4. Pump 100' plug inside and outside (75 sx) from 497-397'. 75 sx used to ensure a good plug.
5. Circ 1 jt at surface.
6. Cut off CSG 4' below ground level, set permanent marker, restore location.
7. Get inspection approval of surface restoration from NMOCC and USGS.

(Plug details given by Larry Brook, NMOCC, and procedure reviewed with him, via telephone 7/23/84).

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Division Engineer

DATE 7/23/84

(This space for Federal or State office use)  
Rodney L. Woodard

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: