

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

OIL CONS COMMISSION

Drawer DD

Artesia, NM 88210

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: September 30, 1990

FEB - 9 1994

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

PARKER & PARSLEY DEVELOPMENT CO.

3. Address and Telephone No.

P.O. BOX 3178 Midland, Tx. 79702 915-683-4768

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660 FSL 1980 FEL Sec. 7 T-17-S R-30-E

5. Lease Designation and Serial No.

NMNM 7752

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Anderson Federal No. 1

9. API Well No.

3001520565

10. Field and Pool, or Exploratory Area

Anderson Penn

11. County or Parish, State

Eddy, N.M.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- (1) Set 5 1/2" CIBP @ 10,800', cap w/35' cement
- (2) Load hole w/mud
- (3) Perforate 5 1/2" casing @ 8650'
- (4) Set 5 1/2" cement retainer @ 8606', unable to pump into formation. Dump 35' cement, T/C.R.
- (5) Spot 25 sack cement plug @ 5200'
- (6) Perforate 5 1/2" casing @ 3550'
- (7) Set 5 1/2" cement retainer @ 3443', squeezed w/105 sacks cement, spot 1 bbl cement on top
- (8) Spot 25 sacks cement plug @ 2848'
- (9) Cut 5 1/2" casing @ 862, pull out of hole
- (10) Spot 30 sacks cement plug @ 907', 5 1/2" stub, W.O.C. Tag @ 766'
- (11) Perforate 8 5/8" casing @ 475'
- (12) Spot 231 sacks cement @ 565', W.O.C., Tag @ 55'
- (13) Spot 55 sacks cement from 55' to surface, set P&A marker

Post ID-2
2-18-94
P&A

14. I hereby certify that the foregoing is true and correct

Signed

Jim Dean

Title

Consultant

Date

1-31-94

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Petroleum Engineer

Date

2/8/94