

1-R. J. STARK-TULSA
1-A. B. CA MIDLAND

1-FILE

N.M.O.C.D. COPY

Form Approved.
Budget Bureau No. 42-R1424

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐

2. NAME OF OPERATOR

Getty Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 730, Hobbs, NM 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE: Unit ~~1~~ K, 1980' FSL & 1980' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☒

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON* ☐

(other) ☐

SUBSEQUENT REPORT OF:

☐

☐

☐

☐

☐

☐

☐

☐

☐

5. LEASE

LC-029410

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Lea "C"

9. WELL NO.

8

10. FIELD OR WILDCAT NAME

Grayburg Jackson

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 11, T-17S, R-31E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3949 DF

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

See attached sheet

RECEIVED
JUL 3 1979
U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

Dale R. Crockett
Dale R. Crockett

TITLE Area Supt.

DATE

7-2-79

(This space for Federal or State office use)

APPROVED BY

(Orig. Sgd.)

ALBERT R. STALL

TITLE

ACTING DISTRICT ENGINEER

DATE

JUL 09 1979

CONDITIONS OF APPROVAL, IF ANY:

LEA "C" WELL NO. 8
WORKOVER PROCEDURE

1. Rig up workover unit and pull rods and tubing.
2. Run work string, 2 7/8" tubing, with a packer and attempt to locate hole in 5 1/2" casing.
3. Pull tubing and rerun with a retrievable bridge plug and packer.
4. Set bridge plug approximately 100' below casing hole and dump 15' of sand on bridge plug.
5. Establish circulation and pump approximately 100 sxs cement into annulus. Close casing valve and squeeze cement.
6. Wait on cement.
7. Run tubing and bit and drill out cement.
8. Test casing.
9. Pull bridge plug and put well back on production.
10. Test well and observe for possible chemical treatment.