

6. SOURCE OF CONSTRUCTION MATERIALS - If needed, construction materials will be obtained from the drill site's excavations or from a local source. These materials will be transported over the access road as shown on Exhibit G.
7. METHODS FOR HANDLING WASTE DISPOSAL
- A. 1. Drill cuttings will be disposed of in the reserve pit.
2. Trash, waste paper, and garbage will be placed in a burn pit and occasionally burned to prevent wind scattering. When the rig moves out, all trash and debris left at the site will be contained to prevent scattering and will be buried at least 36" deep within a reasonable period of time.
3. Mud remaining after completion of the well will be picked up by the supplier, included broken sacks.
4. Sewage from trailer houses will drain into holes with a minimum depth of 10'. These holes will be covered during drilling and backfilled upon completion. A "Port-a-John" will be provided for rig crews. This will be properly maintained during the drilling operations and removed upon completion of the well.
5. Chemicals remaining after completion of the well will be stored in the manufacturers containers and picked up by the supplier.
- B. Remaining drilling fluids will be allowed to evaporate in the reserve pit until the pit is dry enough for backfilling. In the event drilling fluids will not evaporate in a reasonable period of time, they will be transported by tank truck to a state approved disposal site.
- Water produced during testing of the well will be disposed of in the reserve pit.
8. ANCILLARY FACILITIES - No camps or airstrips will be constructed.