

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103 *c195*  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
**30-015-30919**

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
**B-6846**

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well  
Oil Well ☒ Gas Well ☐ Other ☐

1. Name of Operator ☒  
**Clayton Williams Energy, Inc.**

2. Address of Operator  
**Six Desta Drive, Suite 3000, Midland, Texas 79705**

3. Well Location  
Unit Letter **H** : **2285** feet from the **North** line and **330** feet from the **East** line  
Section **20** Township **17S** Range **29E** NMPM County **Eddy**

8. Well No.  
**2**

9. Pool name or Wildcat (28509)  
**Grayburg Jackson-7R's, QN,GB,SA**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
**3602' GR**

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:  
REMEDIAL WORK ☒ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. 4/15/2000 - 4/17/2000

1. Set RBP @ 3790' to temporarily abandon Yeso perfs.
2. Perforate Lower San Andres 3513' - 3768'.
3. Stimulate Lower San Andres. Set RBP @ 3400'.
4. Perforate Upper San Andres 2363' - 3129'.
5. Stimulate Upper San Andres. Set RBP @ 2300'.
6. Perforate Grayburg 2230' - 2269'.
7. Stimulate Grayburg.
8. Retrieve RBP @ 2300' and retrieve RBP @ 3400'.
9. Run tubing. Run pump & rods.
10. Start well pumping load water.



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Betsy Luna* TITLE Regulatory Analyst DATE 5/15/2000

Type or print name Betsy Luna Telephone No. (915) 682-6324

(This space for State use)

APPROVED BY *Simon M. Luna* TITLE SUPERVISOR, DISTRICT II DATE MAY 23 2000

Conditions of approval, if any:

