

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO. **30-015-30971**

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B6846

7. Lease Name or Unit Agreement Name:
STATE '20B'

7. Well No.
9

8. Pool name or Wildcat (28509)
Grayburg Jackson-7R's,QN,GB,SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator ☒
Clayton Williams Energy, Inc.

3. Address of Operator
Six Desta Drive, Suite 3000, Midland, Texas 79705

4. Well Location
Unit Letter **O** : **330** feet from the **south** line and **2310** feet from the **east** line
Section **20** Township **17S** Range **29E** NMPM **Eddy** County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3612' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: **Recompletion** ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

June 22 thru 30, 2000

1. Set RBP @ 3860' and temporarily abandon Yeso perms.
2. Perforate Lower San Andres 3389'-3758', 20 shots. Stimulate Lower San Andres.
3. Set RBP @ 3200'.
4. Perforate Upper San Andres 2517'-3098', 35 shots. Stimulate Upper San Andres.
5. Set RBP @ 2470'.
6. Perforate Grayburg Jackson 2100'-2360', 21 shots. Stimulate Grayburg Jackson.
7. Retrieve RBP's at 2470' and 3200'. Clean out to BP at 3860'.
8. Run tubing, rods and pump.
9. Start pumping load water.



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Betsy Luna TITLE Regulatory Analyst DATE 7/6/00

Type or print name Betsy Luna Telephone No. (915) 682-6324

(This space for State use) Jim W. Brown District Supervisor
APPROVED BY B6A TITLE District Supervisor DATE JUL 12 2000

Conditions of approval, if any: